



**PRODUCT DIMENSIONS**

### INSTALLATION:

1. Centre protective cover over thermostat.
2. Using protective cover as template, mark and drill (6) 3/16 in. (4.7mm) diameter holes as shown.
3. Install the tamperproof fasteners using the supplied spanner bit (STI-9115) or the standard mounting screws (STI-9116)

### CLEANING INSTRUCTIONS

To clean cover, remove from wall. Rinse with water to remove abrasive dust and dirt. Wash with soap or mild detergent using a soft cloth (DO NOT SCRUB). Rinse once more, then dry with a soft cloth or chamois. To remove grease or wet paint, rub gently with a cloth wetted thoroughly with naphtha. Then wash and rinse. DO NOT USE RAZOR BLADES.

## INSTALLATION OF STI-9115 & STI-9116 THERMOSTAT COVERS

All specifications and information shown were current as of publication, and are subject to change without notice.