



Installation Instructions

1. Centre the wire guard over existing clock or bell
2. Loacte clamps around perimtere. Mark and drill (4) holes. See pictorial for size.

Lag Bolts - if lag shields and lag boths are used, make sure rawl plug is flush with surface. Position guard, insert lag bolt and tighten. Length of bold should be selected to assure full thread engagement in rawl plug. For installations that require tamperproof fasteners, order KIT-82 Stainless Steel Screws and 190038 bit.

Model	Diameter	Depth
STI-9631	10.5 in. (267 mm)	6.0 in. (152 mm)
STI-9632	16.5 in. (419 mm)	6.0 in. (152 mm)
STI-9633	20 in. (508 mm)	6.0 in. (152 mm)

Three year warranty or a one year limited warranty (from date of purchase) on most products. See website for details. Electronic warranty form at www.sti-usa.com/wc14.

INSTALLATION OF STI CLOCK/BELL DAMAGE STOPPERS®

All specifications and information shown were current as of publication and are subject to change without notice.

9631 JAN2019

