



INSTALLATION INSTRUCTIONS:

1. Center wire guard over device as shown.
2. Place hinge clamp in upper right position.
3. Mark and drill 1/4" diameter hole
4. Mount wire guard over device using right hinge clamp and tighten screw. This should hold wire guard in place. Mark and drill the remaining 3 clamp holes (if necessary, loosen upper right clamp screw and remove wire guard).
5. Mount wire guard, all 4 clamps and screws. Tighten firmly.

INSTALLATION OF STI-9845 XTRALIS OSID DETECTOR WIRE GUARD

All specifications and information shown were current as of publication and are subject to change without notice.